


devola

Comfortable living everyday

Instruction Manual



Devola Core Mini Oil Filled Radiator

600W: DVMOR7F06B (Black) / DVMOR7F06W (White)
800W: DVMOR9F08B (Black) / DVMOR9F08W (White)
1000W: DVMOR11F10B (Black) / DVMOR11F10W (White)



devola.co.uk

DESCRIPTION

1. Handle
2. Adjustable Thermostat
3. Fins
4. Indicator Light
5. Rear Support
6. Front Support



IMPORTANT SAFEGUARDS

When using the appliance, basic safety precautions should always be followed:

- Please read this instruction manual carefully before use.
- Home use only. Do not use for industrial purposes.
- Before the first use of the appliance check that voltage indicated on the rating label corresponds the mains voltage in your home.
- Danger of electric shock exists even when the appliance is switched off. Always unplug the appliance from the power supply when is not use.
- Oil heater should never be used under conditions where it may be immersed or come in contact with water, and also do not use the appliance in rooms with the increased moistness.
- Do not operate the oil heater with a damaged cord or plug.
- Return malfunctioning appliances for repair to near service center. Repair of the device only by qualified persons.
- Close supervision is required when appliance is used near children.
- Always remove the plug from the power supply before cleaning.
- Unplug oil heater by grasping plug and pulling it from the power supply. Pull on the plug, not on the cord.
- Do not use out of the room.
- Do not insert and pull out the plug with wet hand, as this may cause electrical shock.
- The oil heater must be used only in the upright position.
- The unit should be far away from the object flammable or easily deformed objects during uses.
- Place the oil heater on the floor at least 90 cm away from the wall and any other objects such as furniture, curtains or plants.
- Surface temperature of the appliance is high, thus do not touch it, except the handle.


CAUTION:

- Do not cover the appliance when is use.

- This heater is hot when in use. To avoid burns, do not let bare skin touch hot surfaces. Let the heater cool down before moving. Keep combustible materials, such as furniture, pillows, bedding, paper, clothes and curtains at least 1m away from the front, sides and rear of the heater.

ASSEMBLING

- Do not operate the oil heater without the base support fixed correctly.
- To fix the rear support base, fit it tightly against the fin, until it stays in place.
- To fix the front support base, fit it tightly against the bottom on the front panel.
- After fixing the supports, ensure that the heater is stable on the floor.



USING THE APPLIANCE

- Set the thermostat to the minimal position and plug into a power suitable power source.

THERMOSTAT

- The thermostat will automatically maintain your desired room temperature and will turn on and off based on the temperature you set.
- Turn the thermostat control clockwise all the way round until you hear a click, this sound indicates that the oil heater is activated, the indicator light is ON. Continue turning the thermostat control clockwise to its highest setting.
- When the indicator light is ON, the heater is activated. This light turns ON and OFF automatically according to whether the heater is on or off.
- Turning the thermostat clockwise will always increase the set temperature; turning it anticlockwise will decrease the set temperature.

NOTE:


- The room must be sealed in good condition, if not, the heating will be less effective.
- After use, turn the thermostat to the minimal position and unplug from power supply.
- This heater is fit with tip-over protection so it will cease heating if it falls over.

MAINTENANCE AND CARE

- The oil heater should be cleaned regularly to wipe out the dust on the surface of fins. As this may result the radiating efficient.
- Unplug from the power supply and allow the appliance to cool down.
- Wipe out with a soft damp cloth. Do not use detergent or abrasives.
- Do not scrap the surfaces of fins with sharp hard tools, to avoid surfaces getting rusty, because of damage of the paint coat.

STORAGE

- Ensure the oil heater is completely cool.
- Roll up the power cord in the supports when the heater is not in use.
- Store the appliance in a cool, dry place.





CORRECT DISPOSAL OF THIS PRODUCT

When the time comes to eliminate this product, please consider the environmental impact, and take it to recognised recycling facility instead of disposing it with general household waste. Take the equipment to a waste disposal site. Plastic and metal parts that are used in the construction of this appliance can be separated into pure grade which allow recycling. Ask to your service centre for details.



Product Registration

Register your warranty online
within 30 days of purchase.

www.devola.co.uk/warranty



10% OFF

Use this discount code on your next order

DEV10



View Online

Black



White



devola.co.uk

Unit 1, Reedswood Park Road, Walsall, West Midlands. WS2 8DQ

Helpline 0800 043 8975 Email info@devola.co.uk